



newskill

KIMERA

VIRTUAL 7.1
G A M I N G H E A D S E T

ULTRA COMFORTABLE
HEADBAND

TECHNICAL SPECIFICATIONS

Driver dimension	50 mm
Frequency range	20 Hz - 20.000 Hz
Impedance	32 Ohm +/- 15%
Sensitivity	105dB ± 3dB
Microphone	Flexible
Microphone directivity	Omni directional
Microphone impedance	2.2 K Ohm
Microphone frequency	50 Hz - 10.000 Hz
Microphone sensitivity	-54dB ± 3dB
Connection	Gold-plated USB
Cable length	180 cm
Dimensions	217 x 279 x 105 mm
Weight	270 gr
Compatibility	XP / Vista / 7 / 8 / 10 PlayStation 4

50mm DRIVERS

OMNI-DIRECTIONAL
MICROPHONE

DETACHABLE MICROPHONE

SOFT CUSHIONS



GRAPHIC EQUALIZER

MAIN FUNCTIONS



1. **EQ ON** Enable this function to run* and to create as many custom sound profiles as you like.
2. **Profiles graphic equalizer** Change KIMERA's sound configuration through its graphic equalizer.
3. **3D ON** Enable this function for a greater sound definition and a more immersive bass sound.
4. **Reset** Press to reset sound equalization to its default levels.

* EQ OFF runs a default sound equalization

CREATE A CUSTOM SOUND PROFILE



1. **EQ ON** Enable this function to be able to create and save your custom sound profile.
2. **Sound profile equalization** Adjust sound levels as you like through KIMERA's graphic equalizer.
3. **Save** Click Save and choose a path into your computer to save your new custom sound profile. You can create and save as many as you like.

GRAPHIC EQUALIZER


LOAD A CUSTOM SOUND PROFILE



1. **EQ ON** Enable this function to be able to upload custom sound profiles.
2. **Choose the profile** where to upload and run your custom sound equalization.
3. **Load** Click Load and choose the saved custom sound profile you want to run.

Double click its icon: it will load in the selected sound profile.

ENVIROMENTAL EFFECTS



You can add environmental effects to enhance your custom sound profiles, simulating certain sound scenes. You can choose between 4 different environments:

[Theater](#) | [Bathroom](#) | [Living Room](#) | [Corridor](#)

Environmental effect set by default is None. This set of effects is not editable

LED EFFECTS



With the "LED" button you can change the lighting of KIMERA to your liking. Choose from different colors and rotating color effect.

MICROPHONE



1. **Boost** Enable this function to enhance microphone's transmission performance.
2. **Gain** Set KIMERA's microphone gain level that suits you best.
3. **Mute** As well as through its inline controller, you can mute KIMERA's microphone through its software interface.

VIRTUAL 7.1 SOUNDSCENE



1. **Virtual 7.1** soundscape ON Enable this function to run and to be able to customize KIMERA's virtual 7.1 soundscape.
2. **Soundscene** speakers Pick and move each speaker to recreate the soundscape that suits you.
3. **CCW** Rotates soundscape in a clockwise direction.
4. **CW** Rotates soundscape in a counterclockwise direction.
5. **Reset** Press to reset KIMERA's virtual 7.1 soundscape to default.



 newskill **KIMERA** VIRTUAL 7.1
GAMING HEADSET